

XP™ and XP-hf™ PressureTrak Kit

3A3320E

EN

Monitors pressures to provide ratio assurance on XP and XP-hf plural-component sprayers in hazardous or non-hazardous locations. For professional use only.

17G807: N3400 PressureTrak Kit

17G808: N6500 PressureTrak Kit



17N936: XP-hf PressureTrak Kit

See page 2 for **Agency Approvals**.



Important Safety Instructions

Read all warnings and instructions in this manual and the XP-hf sprayer operation manual. Save these instructions.






Contents

Related Manuals	2	Repair	20
Agency Approvals	2	Replace the PressureTrak Module Battery or Fuse	20
Warnings	3	Retract a Solenoid With a Dead Battery	21
Overview	5	Parts	22
Operating Window	5	Kits 17G807 and 17G808	22
Component Identification	6	Kits 17N936	23
XP Proportioner (Model 571100 Shown)	6	Appendix A: User Setup Display	24
XP-hf Proportioner (Model 572407 Shown)	7	Setup Mode Details	24
User Interface	8	Setup Screen 1	24
Display Screens	9	Setup Screen 2	25
Installation	10	Setup Screen 3	25
Installation for XP System with NXT Motor	10	Set Password	26
Installation for XP-hf System with Xtreme XL Motor	12	Appendix B: Run Screen Details	27
Operation	14	Circulation Mode	27
Startup	14	Spray Mode Active	27
Shutdown	14	Alarm Active	27
Setup	14	Deviation Active	28
Alarms, Deviations, and Advisories	15	Information Screen	28
Clear Alarms	15	Manual Bypass Mode	28
View Current Alarms	16	Accessories	29
View Error Log	16	Technical Specifications	29
Error Codes	17	Graco Standard Warranty	30

Related Manuals








Manual in English	Description
3A3320	PressureTrak Manual, English
3A0420	XP Sprayer, Instructions and Parts
3A4381	XP-hf Proportioner, Operation, Repair and Parts
334644	XL 10000 Air Motor

Agency Approvals

Model	Agency Approval
17N936	   <p>9902471 Class I, Div. 1, Group D T3A</p> <p>0359</p> <p>Ex ia IIA T3 Ga ITS13ATEX27862X</p>
17G807	
17G808	

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

 <h2 style="margin: 0;">WARNING</h2>	
 	<p>SPECIAL CONDITIONS FOR SAFE USE</p> <p>Equipment must comply with the following conditions to avoid a hazardous condition which can cause fire or explosion.</p> <ul style="list-style-type: none"> • All label and marketing material must be cleaned with a damp cloth (or equivalent). • The electronic monitoring system is required to be grounded. See Grounding instructions in your pump operation manual.
   	<p>FIRE AND EXPLOSION HAZARD</p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. Paint or solvent flowing through the equipment can cause static sparking. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> • Use equipment only in well-ventilated area. • Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static sparking). • Ground all equipment in the work area. See Grounding instructions in your pump operation manual. • Never spray or flush solvent at high pressure. • Keep work area free of debris, including solvent, rags and gasoline. • Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present. • Use only grounded hoses. • Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are anti-static or conductive. • Stop operation immediately if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem. • Keep a working fire extinguisher in the work area.

Overview

The purpose of the XP PressureTrak is to shut down the sprayer if abnormal pressure conditions are detected in order to prevent spraying material that is not mixed on ratio.

Two pressure transducers read the A and B fluid pressures in the outlet manifold and send the readings back to the XP PressureTrak.

The XP PressureTrak monitors the difference between the A and B fluid pressures, alerting the user when an imbalance is detected. An imbalance may be due to a plug, leak, or running out of fluid.

When an imbalance is detected, the electric solenoid disables the air motor, an alarm is displayed on the screen, and the LED on the front of the display flashes. For more error code information see **Alarms, Deviations, and Advisories** page 15.

The following alarms can occur:

- Differential Pressure (B>A)
- Differential Pressure (A>B)
- Pressure A High
- Pressure B High
- Electric Solenoid Disconnected
- Pressure A Disconnected
- Pressure B Disconnected
- Low Battery
- Blown Fuse

Operating Window

Below Minimum Spray Pressure

The air motor is allowed to automatically operate in Circulation Mode any time the fluid pressures are below the minimum spray pressure. This allows for loading the system and circulating the fluids without alarms or shutdowns.

Above Minimum Spray Pressure

When the XP PressureTrak detects the fluid pressures above the minimum spray pressure for 30 seconds, and the pressures are balanced within the pre-set limits, it will automatically start pressure monitoring. If the XP PressureTrak does not see balanced pressures within 30 seconds of going above the minimum spray pressure it will detect the fault and disable the air motor. The default minimum spray pressure is 2000 psi (14 MPa, 138 bar). Enter Setup Mode to change the minimum spray pressure as necessary (see **Setup Mode Details**, page 24).



Maximum Spray Pressure

The XP PressureTrak will alarm and shutdown if it detects either A or B fluid pressures above the maximum working pressure (see table below). Enter Setup Mode to reduce the maximum allowable pressure set point (see **Setup Mode Details**, page 24).

Model	Maximum Spray Pressure
17C807	7250 psi (500 Bar, 50 MPa)
17C808	
17N936	7250 psi (500 Bar, 50 MPa)


Component Identification

XP Proportioner (Model 571100 Shown)



Ref.	Description
XA	Module
XB	Housing
XC	Cover
XD	Pressure Sensors
XE	Solenoid
XM	Air Motor

XP-hf Proportioner (Model 572407 Shown)





Ref.	Description
XA	Module
XB	Housing
XD	Pressure Sensors
XE	Solenoid
XM	Air Motor

User Interface









Table 1: LCM Button Functions

Button	Function
Arrows Up/Down 	Navigate up or down within a screen or to a new screen.
Soft Keys 	Soft keys activate the mode or action represented by the icon next to each soft key. See Table 2 for soft key icons and actions. Top Soft Key: Edit data, accept edited data, or move right within a selected field. Bottom Soft Key: Enter a screen, exit a screen, or cancel edited data.

NOTICE

To prevent damage to soft key buttons, do not press the buttons with sharp objects such as pens, plastic cards, or fingernails.

Table 2: Display Soft Key Icons


Icon	Function
	In screens that have editable fields, press to access the fields and make changes.
	In screens that have editable fields, press to exit edit mode.
	In screens that have editable fields, press to make data selections or to enter changes.
	In screens that have editable fields, press to move to the right while in a field.
	Cancel a selection or edited data. Returns to the original data.
	Clear entire error log.

NOTE: The display will turn OFF after one minute of inactivity to save battery life. The PressureTrak will continue to monitor the pressures. Press any key to wake the XP PressureTrak display.


Display Screens

Table 3: **Display Screens**, identifies components shown on the Spray Mode Active, Circulation Mode Active, Alarm Active, and Deviation Active Run screens. For more information see **Appendix B: Run Screen Details**, page 27.


Spray Mode Active Screen



Circulation Mode Active Screen



Alarm Active Screen



Deviation Active Screen




Table 3: Display Screens

Icon	Function
	Actual spray pressures.
	Differential pressure alarm bar graph and pressure units.
	Indicates that you are in spray mode.
	Indicates that you are in circulation mode.
	Indicates that there is an active alarm.
	Indicates that there is an active deviation.

Installation

Installation for XP System with NXT Motor



To reduce the risk of skin injection and shock, shut down the XP Sprayer before installing your XP PressureTrak. Follow the **Shutdown** and **Pressure Relief** procedures in the XP Sprayer operation manual.

The procedures in this section are specific to each component of the XP PressureTrak. For sprayer installation instructions, refer to the sprayer operation manual.


1. Perform **Pressure Relief Procedure**. See your XP Sprayer manual.
2. Remove the existing NXT air motor cover and front (D) of the motor cover.
3. Remove the insert from the solenoid hole (F).
4. Install the solenoid (XE). Use the retainer (G) and two bolts (H) to secure the solenoid.

NOTE: The holes in the casting may not have threads, but the screws are thread-forming.

5. Pass the pressure sensor (4a and 4b) through slot (K) and the solenoid (XE) through slot (J) in the housing (XB) and secure the housing to the air motor with two bolts (6).
6. Reinstall the front (D) and install the XP PressureTrak cover (3).
7. Connect the pressure sensor cables to the connectors on the circuit board.

NOTE: Be sure to match the color codes (connect the blue cord to J6, circuit board labeled A and green cord to J7, circuit board labeled B). Connect the solenoid to J3, then connect the battery to the battery terminals.
8. Slide the module (XA) into the channel of the housing (XB) and secure with two screws (5).
9. Insert o-ring (11) on pressure sensor (XD). Lubricate o-ring and install into the A side (blue) of the manifold. Torque sensor nut to 40-50 in-lb (54-67 N•m). Insert o-ring (11) on pressure sensor (XD). Lubricate o-ring and install into the B side (green) of the manifold. Torque sensor nut to 40-50 in-lb (54-67 N•m).
10. Install the pressure sensor harness (XD) through clamp (10) and secure to the frame with screw (8) and nut (9).

XP System with NXT Motor



Installation for XP-hf System with Xtreme XL Motor




To reduce the risk of skin injection and shock, shut down the XP Sprayer before installing your XP PressureTrak. Follow the **Shutdown** and **Pressure Relief** procedures in the XP Sprayer operation manual.

The procedures in this section are specific to each component of the XP PressureTrak. For sprayer installation instructions, refer to your sprayer operation manual.

1. Perform **Pressure Relief Procedure**. See your XP-hf Proportioner manual.
2. Remove the two top bolts (L) on the XL motor manifold. Use the bolts to install the XP-hf PressureTrak module.
3. Remove the plug (126) and O-ring (125) by removing the retaining ring (127).
4. Remove two right side bolts (23) from the XL motor valve.
5. Install solenoid (8) into the solenoid hole.
6. Bolt down the solenoid holding bracket (17) with two bolts while pushing the bracket to the left to hold the solenoid tight in the hole.
7. Insert o-ring (19) on pressure sensor (7). Lubricate o-ring and install into the A side (blue) of the manifold. Torque sensor nut to 40-50 in-lb (54-67 N•m). Insert o-ring (19) on pressure sensor (7). Lubricate o-ring and install into the B side (green) of the manifold. Torque sensor nut to 40-50 in-lb (54-67 N•m).
8. Install the pressure sensor harness (XD) through clamp (20) and secure to the frame with screw (4).
9. Remove screws (9) to slide out module (6).
10. Connect the battery to the battery terminals.
11. Slide the module (XA) into the channel of the housing (XB) and secure with two screws (9).

XP-hf System with Xtreme XL Motor



31457b

Operation

Startup

1. Refer to your XP sprayer operation manual for sprayer startup instructions.

NOTE: The XP PressureTrak modifies XP sprayers. However, the operation procedures from the XP sprayer operation manual still apply.

2. Press any key to wake the XP PressureTrak. The display will turn off in one minute to save battery life, but will continue to monitor the pressures.

NOTE: To enter into Setup, press and hold any button for three seconds.

Shutdown


Refer to your XP sprayer operation manual for sprayer shutdown instructions. The XP PressureTrak will enter a hibernation mode to save battery life.


Setup

1. To enter into Setup, press and hold any button for three seconds.
2. Set the system parameters before spraying. These can be changed as necessary (see **Setup Mode Details**, page 24).




Alarms, Deviations, and Advisories

There are three types of errors that can occur: Alarms, Deviations, and Advisories. Errors are indicated by the flashing red LED as well as on the display.




Alarms, indicated by , require immediate attention; therefore, the XP PressureTrak disables the air motor and the alarm screen automatically displays.




Deviations, indicated by , require attention, but not immediately.

Advisories, indicated by , do not require attention. Therefore, if a deviation or advisory occur, the system continues running and  or  is displayed on the run screen.

The following table shows the status of the front LED for Alarms and Advisories.

Front LED	Description
OFF	System is powered up and monitoring pressure.
OFF	In Circulation Mode or Manual Bypass Mode. 
OFF	A deviation exists. 
Red Flash	An alarm exists and the system shuts down. 

Clear Alarms

1. Turn the air valve to OFF.
2. Reduce the air pressure regulator to minimum.
3. Wait for the air pressure to drop.
4. XP-hf only: Press the manual shuttle override button on your air motor air valve. Refer to your air motor manual.
5. Clear the cause of the error.
6. Press  .


NOTE: If the system has air pressure when  is pressed, the screen will display how to reset the system and clear an alarm. See FIG. 1 or FIG. 2. Press the lower arrow key to stop the demonstration sequence and return to the alarm screen.



FIG. 1: XP PressureTrak Sequence




FIG. 2: XP-hf PressureTrak Sequence


7. Turn the air valve to ON.
8. Increase the pressure to achieve the best pattern.

NOTE: When trying to clear an error and the screen displays the “X”, the unit did not retract the solenoid and is in an 8 second delay period before an attempt can be tried to retract the solenoid. Verify air pressure has dropped.

View Current Alarms


To toggle the screens between the Alarm Information screen and the Run Alarm Active screen,

press  or .









View Error Log






Setup Screen 3 is the error log screen. It displays the most recent error on the top of the list with the past 20 errors below it. This screen displays a list of advisory or alarm error codes and the time the error occurred since the unit went to spray mode. The timer will restart when the pressure falls and unit enters into circulation mode, or when the timer rolls over 23:59.







Error Codes

Code	Icon	Code Name	LED Status	Cause	Solution
Alarms					
J4AX		Differential Pressure (A>B)	Flashing Red	Ran out of B side material.	Refill hopper or change drum.
				Cavitating B side pump.	Warm material or add feed pressure.
				B material leaking.	Follow pump troubleshooting in XP70 Sprayer manual.
				No mix manifold B side restriction.	Add restriction to B side on mix manifold to balance pressures.
				A side hose is too small.	Change to larger hose size.
				Too much B side offset in control setup.	Adjust B side offset in setup screens if B normally runs at a higher pressure than A. See Setup Screen 2 , page 25.
				Improper configuration.	Adjust setpoints on setup screens. See Setup Mode Details , page 24.
J4BX		Differential Pressure (B>A)	Flashing Red	Ran out of A side material.	Refill hopper or change drum.
				Cavitating A side pump.	Warm material or add feed pressure.
				A material leaking.	Follow pump troubleshooting in XP70 Sprayer manual.
				Too much restriction on mix manifold B side restriction.	Reduce restriction to B side mix manifold.
				*B side hose is too small.	Change to larger diameter hose size.
				*No B side offset in control setup.	Adjust B side offset in setup screens if B normally runs at a higher pressure than A. See Setup Screen 2 , page 25.
				Improper configuration	Adjust setpoints on setup screens. See Setup Mode Details , page 24.
P6AX		Pressure A Disconnected	Flashing Red	Broken cable.	Replace transducer.
				Disconnected cable.	Connect cable
P6BX		Pressure B Disconnected	Flashing Red	Broken cable.	Replace transducer.
				Disconnected cable.	Connect cable.
WJPX		Air Solenoid Disconnected	Flashing Red	Broken cable.	Replace cable.
				Disconnected cable.	Connect cable.
				Damaged solenoid.	Replace solenoid.
P4AX		Pressure A High	Flashing Red	A pressure exceeding maximum working pressure at setpoint.	Reduce air pressure to motor or adjust setpoint.

* Remote mix manifold applications only.

Code	Icon	Code Name	LED Status	Cause	Solution
Alarms					
P4BX		Pressure B High	Flashing Red	A pressure exceeding maximum working pressure setpoint.	Reduce air pressure to motor or adjust setpoint. Open down stream valve.
				Too much restriction on mix manifold B side restriction.	Reduce restriction to B side on mix manifold.
				Blockage in B line downstream.	Reduce downstream restriction. Clean mix manifold.
BATT		Low Battery	Flashing Red	Battery is low. NOTE: If the battery is less than 8.5 volts, this alarm is shown. If the battery is less than 8.3 volts this alarm is shown and the solenoid pin is extended to stop the pump.	See Repair , page 20.
FUSE		Blown Fuse	Flashing Red	Fuse is blown.	See Repair , page 20 for information on how to check the fuse.
				Fuse not seated in fuse holder.	Place fuse in fuse holder.
				Bent pins on the fuse.	Straighten pins on the fuse, install back into fuse holder.
		System Pressurized	Flashing Red	The PressureTrak controller detected air pressure when trying to clear an alarm. NOTE: The images in the code and icon columns will display on your screen. These screens demonstrate how to properly clear an alarm. Press the lower left arrow to stop the demonstration sequence and return to the alarm screen.	Shut off air pressure and wait for air pressure to drop. NOTE: XP-hf only: Press the valve pin fully into the valve. Press  to follow remaining prompts to clear the alarm. See Clear Alarms , page 15.

❖ Only the XP-hf will have these images if the air pressure is not turned down.

Code	Icon	Code Name	LED Status	Cause	Solution
Deviations					
J3AX		Differential Pressure (A>B)	OFF	Ran out of B Side B material.	Refill hopper or change drum.
				Cavitating B side pump.	Warm material or add feed pressure.
				B material leaking.	Follow pump troubleshooting in XP70 Sprayer manual.
				No mix manifold B side restriction.	Add restriction to B side on mix manifold to balance pressures.
				A side hose is too small.	Change to larger hose size.
J3BX		Differential Pressure (B>A)	OFF	Ran out of A side material.	Refill hopper or change drum.
				Cavitating A side pump.	Warm material or add feed pressure.
				A material leaking.	Follow pump troubleshooting in XP70 Sprayer manual.
				Too much restriction on mix manifold B side restriction.	Reduce restriction to B side on mix manifold.
				*B side hose too small.	Change to a larger hose size.
				*No B side offset in control setup.	Add B side offset in setup screen.
Events and Advisories					
EERX		Under Minimum Spray Pressure, Circulation, Loading	OFF	Under minimum spray pressure.	Normal for circulation mode.
EVRX		Entered into spray mode	OFF	Pressure went above minimum spray limit.	Normal for spray mode.

* Remote mix manifold applications only.

Repair


Replace the PressureTrak Module Battery or Fuse




The battery and fuse must be replaced in a non-hazardous location.

1. Remove the two screws (135). Carefully slide the PressureTrak module (131) out of the housing (132).

XP System



XP-hf System



2. Disconnect the electric solenoid (7) and pressure sensor cables (4) from the module board.
3. Take the PressureTrak module (131) to a non-hazardous location



Use only the following approved replacement batteries. Use of an unapproved battery will void the Graco warranty, as well as Intertek and Ex approvals.

- Ultralife® brand lithium U9VL
- Duracell® brand alkaline MN1604
- Energizer® brand alkaline 522
- Varta® brand alkaline 4922.

4. **To replace the battery**, disconnect the used battery and replace with an approved battery.




Use only a Graco-approved replacement fuse (12) Graco part number 24V216

5. **Checking the fuse (12):**

- a. Remove the fuse from the circuit board.
- b. Use an ohm meter to measure the resistance of the fuse.
NOTE: Less than 6 ohms means the fuse is good. 6 ohms or more means the fuse must be replaced.

6. **To replace the fuse (12):**

- a. Pull the fuse away from the board.
- b. Replace with a new fuse (12).




ti28522a

Retract a Solenoid With a Dead Battery

First replace the battery and clear the error (this will retract the pin). If no replacement battery is available, complete the following steps to retract the solenoid.

1. Remove cover (3), front (D), and retainer (G).
2. Push pin back into solenoid (7).
3. Reinstall solenoid (7), retainer (G), front (D), and cover (3).




ti27512a

NOTE: For more detail on parts orientation, see **Installation**, page 10.

Parts


Kits 17G807 and 17G808



Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	24Y281	MODULE, hazardous location pressure monitor	1	7	NXT403	SOLENOID, locking, DC	1
2	24Y932	HOUSING, PressureTrak, machined	1	8	-----	SCREW, flanged, hex head	1
3	17G839	COVER, PressureTrak, NXT3400	1	9	-----	NUT, hex, flange head	1
	17G840	COVER, PressureTrak, NXT6500	1	10	-----	CLAMP, cable	1
4	17G837	SENSOR, PressureTrak, assembly	1	11	-----	PACKING, o-ring	2
5	-----	SCREW, high-low, flat head #6 x 0.625	2	12	24V216	KIT, repair, fuse assembly	1
6	-----	SCREW, thread forming	2	13▲	15F716	LABEL, warning	1
				14	NXT405	KIT, membrane shield	1

▲ Replacement Danger and Warning labels are available at no cost.

Kits 17N936



Ref.	Part	Description	Qty.	Ref.	Part	Description	Qty.
1	17P845	BRACKET	1	9	120279	SCREW, high-low, flat head #6 x 0.625	2
2	16C251	GROMMET	1	12	24V216	KIT, repair, fuse assembly	1
3	24Y932	HOUSING	1	13▲	15F716	LABEL, warning	1
4	113161	SCREW	2	18	NXT405	KIT, membrane shield (pack of 20)	1
5	115942	NUT, hex, flange head	2	19	121399	PACKING, o-ring	2
6	24Z940	MODULE	1	20	128769	CLAMP, cable	1
7	17R447	SENSOR, PressureTrak, assembly	2				
8	15F477	SOLENOID, locking, DC	1				

▲ Replacement Danger and Warning labels are available at no cost.

Appendix A: User Setup Display

Setup Mode Details


Set the system parameters before spraying. These can be changed as necessary. Press and hold any of the four keys on the User Interface Display for three seconds and the XP PressureTrak will enter into the Setup Mode.

Setup mode screens enable the user to view or modify system configuration data. The user can set:

- Units of pressure
- Differential pressure deviation value
- Differential pressure alarm value
- High pressure limit value
- Minimum spray pressure value
- Normal B pressure offset value

Setup Screen 1


Setup Screen 1 enables the user to set units of measurement that will display on other screens, pressure warning and pressure alarm. Additionally, this screen displays the software number and version. Refer to the following table for more information.



Icon	Function
	<p>Deviation Pressure</p> <p>Adjust the differential pressure deviation setpoint.</p> <p><i>Default: 400 psi (2.75 MPa, 27.5 Bar)</i></p> <p><i>Range: 0-2000 psi (13.8 MPa, 138 Bar)</i></p>
	<p>Alarm Pressure</p> <p>Adjust the differential pressure alarm setpoint.</p> <p>This is the main setting that determines how far apart the A and B pressures can be before shutting down the machine. If the machine shuts down too easily, increase this to a higher setpoint.</p> <p><i>Default: 600 psi (4.13 MPa, 41.3 Bar)</i></p> <p><i>Range: 0-2000 psi (13.8 MPa, 138 Bar)</i></p>

Setup Screen 2

Setup Screen 2 enables the user to set the high spray pressure alarm limit value, minimum spray pressure value, and B pressure offset. refer to the following table for more information.



Icon	Function
	<p>High Pressure Limit</p> <p>Adjust the high pressure limit.</p> <p>XP Systems:</p> <p><i>Default: 7250 psi (50 MPa, 500 Bar)</i></p> <p><i>Range: 0-7250 psi (50 MPa, 500 Bar)</i></p> <p>XP-hf Systems:</p> <p><i>Default: 7250 psi (50 MPa, 500 Bar)</i></p> <p><i>Range: 0-7250 psi (50 MPa, 500 Bar) maximum</i></p>
	<p>Minimum Spray Pressure Limit</p> <p>Adjust the lower spray pressure limit.</p> <p><i>Default: 2000 psi (13.8 MPa, 138 Bar)</i></p>
	<p>B Side Pressure Offset</p> <p><i>Default: 0 psi (0 MPa, 0 Bar)</i></p> <p><i>Range: -999 - +999 psi (-9.9 - +9.9 MPa, -99.9 - 99.9 Bar) maximum</i></p> <p>Only used for remote mix manifold applications where there is a normal difference in pressure between A and B. Remote mix manifold applications should first be balanced with proper house sizing and adjusting the mix manifold B restrictor. See manual 3A0590.</p> <p><i>Use this if the differential alarm bar graph on the Spray Screen is off to one side under normal spray conditions.</i></p>
	<p>Password</p> <p>The setup screens can be protected by a password to restrict their accessibility. To set the password, see Set Password, page 26. To deactivate the password, enter 0000.</p> <p><i>Default: 0000 (not active)</i></p> <p><i>Range: 0-9999</i></p>

Setup Screen 3

Setup Screen 3 enables the user to scroll through all errors and clear the entire error log. The error log will display the most recent error on the top of the list. Refer to the following table for more information.




Icon	Function
	<p>Error Number</p> <p>The first column lists the error number. Once the system has more than the maximum errors allowed, then the oldest error will be over-written.</p> <p><i>Maximum: 20</i></p>
	<p>Error Code</p> <p>The second column lists the error codes (see Error Codes, page 17).</p> <p><i>Maximum: 20</i></p>
	<p>Time</p> <p>The third column shows the time that the error occurred since the unit was last powered on. The time will always start at 0:00 when the system is powered up. This time will be logged as code ELCX.</p> <p><i>Format: Hours: Minutes</i></p> <p><i>Maximum: 23:59</i></p>
	<p>Reset</p> <p>Press the Reset icon to clear the entire error log.</p>

Set Password

NOTE: When the password is “0000” the setup screens can be accessed without entering a password.


1. Navigate to Setup Screen 2.



2. Press to access fields to make changes.
3. Press to navigate to the password field.
Press to edit data.
4. Press and to increment or decrement to the desired digits of the password.
5. Press to accept the password or press to cancel.
6. Press to exit edit mode.

NOTE: The password screen is shown when the setup screens are accessed and the password function has been enabled by changing the “0000” password.


NOTE: If you set and forget the password, please contact Graco Technical Assistance for a default password.



Appendix B: Run Screen Details


The graph on the bottom of the display shows the magnitude of the differential pressure in relation to the deviation and alarm setpoints. If the moving bar is in the center, clear area of the graph (the pressures are within tolerance). If the moving bar is in the dotted area of the graph, the pressures are in the deviation setpoint. If the moving bar moves to either end of the graph, the pressures are in the alarm setpoint and the PressureTrak Monitor will alarm.

NOTE: Under normal spray conditions, if the moving bar is not centered, use the B Side Pressure Offset to center the bar. See **Setup Screen 2**, page 25.



Circulation Mode

This is the display screen that appears after the power up screen. A and B pressure are shown. In Circulation Mode, all alarms are disabled except for the Air Solenoid disconnected High Pressure A, and High Pressure B alarms.




Icon	System Status
	Indicates that you are in Circulation Mode and the fluid pressure is below the Lower Spray Pressure Limit. All alarms are disabled except for Air Solenoid Detection, High Pressure A, and High Pressure B alarms.

Spray Mode Active

This is the display screen that appears during spray mode. A and B pressure are shown.

When the pressure first gets above the lower spray pressure limit, the user has 30 seconds to balance the system differential pressure so it is less than the differential pressure deviation and alarms limits. Then the system will automatically go into Spray mode and start monitoring all alarms and deviations.



Icon	System Status
	Indicates that you are in spray mode, at least one of the pumps has pressure greater than the lower spray pressure limit, and the differential pressure is less than the differential pressure deviation setpoint.

Alarm Active

This is the display screen that appears during an active alarm. A and B pressures shown are the current pressures of the system. The information screen captures the pressure at the time of the alarm. To toggle between the Alarm Active screen and the Alarm Information screen, press either the or .




Refer to the following table for more information.

Icon	System Status
	Indicates that there is an active alarm.

Deviation Active

This is the display screen that appears during an active deviation. A and B pressure are shown. Refer to the following table for more information.




Icon	System Status
	Indicates that there is an active deviation.

Information Screen

The information screen is displayed when an alarm is active. It shows the active alarm code and the A and B pressure conditions at the time of the alarm, if applicable.

To toggle between the Alarm Active screen and the Alarm Information screen, press:



The red LED will flash when an alarm is present. Refer to the following table for more information.

Icon	System Status
	Indicates that there is an active alarm. The red light on the front LED will be flashing and the system is disabled.
J4BX	Alarm Active Code (see Error Codes , page 17).

NOTE: To clear the alarm, see **Clear Alarms**, page 15.

Manual Bypass Mode

If the user needs to spray with one of the above errors active, set the Lower Spray Pressure Limit equal to the High Pressure Alarm Limit to enter Manual Bypass Mode. Only use Manual Bypass Mode for emergency operation. The XP PressureTrak no longer monitors the pressures and will not shut off the sprayer.

Accessories

Part	Description
NXT405	Membrane Shield Kit (20 shields included) Removable clear shield to protect the membrane switch from daily wear.

Technical Specifications

System	
Fluid pressure range:	XP Systems: 200–7250 psi (1.4–50 MPa, 13.8–500 Bar) XP-hf Systems: 200–7250 psi (1.4–50 MPa, 13.8–500 Bar)

Graco Standard Warranty

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty must be brought within two (2) years of the date of sale.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

For patent information, see www.graco.com/patents.

TO PLACE AN ORDER, contact your Graco distributor or call to identify the nearest distributor.

Phone: 612-623-6921 or Toll Free: 1-800-328-0211 Fax: 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication. Graco reserves the right to make changes at any time without notice.

Original instructions. This manual contains English. MM 3A3320

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA
Copyright 2016, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com
Revision E, July 2018