


PressureTrak[™]

Provides Ratio Assurance for XP[™] Sprayers for Explosive Atmospheres



Take control of protective coatings projects with PressureTrak

With an optional PressureTrak installed on your Graco XP Plural-Component Sprayer, you have the assurance that you're spraying on-ratio. If off-ratio conditions occur, the sprayer automatically shuts down. The kit detects off-ratio conditions including:

- Running out of material
- Pump cavitation
- · Packing failures
- · Leaks in valves or fittings
- Plugged filters

PressureTrak includes:

- PressureTrak Module with housing displays A & B pressures while you're spraying
- Pressure transducers
- Solenoid to stop air motor
- · Air motor cover

Ordering Information

17G807 PressureTrak for XP35

17G808 PressureTrak for XP50 and XP70

17N936 PressureTrak for XP-hf

3A3320 Operation and parts manual

On-ratio spraying means peace of mind

- Provides assurance that your XP is spraying accurately and on-ratio
- Improved efficiency means you get it done right the first time and within the scheduled timeframe
- Reduced rework saves you labor and material costs
- Improved quality control you have more confidence in end results
- Easily retrofits to any XP can be installed in less than 30 minutes

How it works

Two pressure transducers read the A and B fluid pressures in the outlet manifold and send the readings back to PressureTrak. When A to B differential spray pressure is out of tolerance, PressureTrak shuts off the proportioner and the alarm code appears on the display.



Contact us today!

Call **877-844-7226** to talk with a Graco representative, or visit **www.graco.com** for more information.

